

O-RINGER TOOL INSTRUCTIONS

Make sure the bottom end of the tool has the abrasive disc attached to it. There should be an outer and an inner disc attached on to the bottom. These abrasive discs have a self-adhesive side to them, just peel off the plastic covering and place them on the tool.

The thread end of the post is to be threaded all the way into the cylinder until it stops. This should be done by hand no tools should be required. This is to prevent any particles going into the cylinder and also is the depth gauge for the O-Ringer tool.

Then slide the tool over the post making contact with the cylinder surface of the gland area. Make several rotations until the surface area appears to be free and clean of all corrosion.